

Housing Dimensions in mm...

Weight

Battery

Battery life .

Approx


∕Go



testo 174

D (GB)

操作手册 Overview



0973.1742/T/wh/PC_qxd/03.02

① 显示器 (GB) Display

保存的最小读数/ Lowest reading saved 保存的最大读数 / Highest reading saved 等待测量程序启动 / Waiting on measuring program to start 启动模式:定时启动/ Start criterion: Programmed date/time 结束测量程序/ Measuring program finished 测量程序正在运行 / Measuring program is running Rec End O Wait Max Min 选数 / Readings 上限报警值*/ Top alarm value 下限报警值*/ Bottom alarm value 单位 / Units 电量 / Battery capacity

- * 闪烁:显示设定的报警限值 亮起:测量值超过设定的报警限值
- * Flashes: Programmed alarm value is displayed Lights up: Programmed alarm value has been exceeded

(D) 电量

...0.1 °Ć

...IP 65

..(lxwxh) 55 x 35 x 17

..Approx. 500 days (with Testo battery)

...CR 2032 lithium

ARS

...24a

(B) Battery capacity

标识	电量	Capacity
	75 ~ 100%	75 to 100%
	50 ~ 75%	50 to 75%
	25 ~ 50%	25 to 50%
■ 0	10 ~ 25%	10 to 25%
	<10%	<10%
□LO	电池用尽 ▶读取数据 ▶ 更换电池	Battery empty • Read out data • Change battery

(D) 注意!

此简明操作手册仅提供简单的帮助说明。

(GB) Please note the following:

This overview is intended as an additional aid on site. If you wish to operate or program the data logger, please read the Instruction manual included with the starter kit or the interface.

取标准

合格证书证明本产品 符合89/336/EEC标准

本产品符合EN 12830标准: 适用于: S(存储), T(运输) 用于: C(食品仓储和分销系统) 量程: -30~+70℃

(GB) Standards

The conformity certificate confirms that this product meets the guidelines in accordance with 89/336/EEC.

This product meets the guidelines corresponding to EN 12830 standard: Suitability: S (Storage), T (Transport) Location: C (Food storage and distribution systems) Accuracy class: 1

Measuring range: -30 to +70 °C

D 安全使用指导

请仔细通读以下安全使用指导:

- ▶不要使用testo 174来测量带电物体!特别是记录仪背面的读数接口, 定要远离带电体。
- ▶ 仪器仅可在技术数据中所提及的参数范围内操作。
- ▶小心轻放testo 174
- ▶仅在操作手册中特意提及的特定情况下,才可打开仪器。
- ▶不可对仪器施强力!
- ▶在testo 174报废时,请直接将其寄回我们公司,我们将 妥善处理。

(GB) Safety instructions

Please read through the following safety instructions carefully:

- Never use the **testo 174** to measure on live parts! Especially the read out contacts on the back of the logger should be kept away from live parts.
- ▶ The instrument should only be operated within the parameters specified in the Technical data.
- Please handle the testo 174 with care.
- The instrument should only be opened if expressly described in the Instruction manual for maintenance purposes.
- Force should never be applied.
- You can return your testo 174 directly to us at the end of its service life. We will dispose of it responsibly.

(D) 保修期

1年

(GB) Warranty

1 years